
FLOW CHART WOOD FLOORING INSTALLATION UP TO 4 STEPS

- Identify Your Subfloor type & assess the risk of moisture present
- Is a 'DPM'' Chemical moisture suppressant required?

۲

- Is the slab pre 1965? Can it be assumed there is no physical DPM?
- Have you performed a moisture test, using reliable and correct methods? (Hygrometer box)
- Are the moisture testing methods in accordance with British Standards 65% RH or below?
- Is the floor solid and stable, no decay, flaky paint, no movement, has laitance been removed
- Concrete bases 150mm thick often take more than a year to dry from the face only!



۲

۲